



MICROSCOPY 101

We appreciate the response to this publication feature - and welcome all contributions. Contributions may be sent to Phil Oshel, our Technical Editor at:

Mr. Phil Oshel (608)833-2885
 PO Box 620068 Fax: (608)836-1969
 Middleton WI 53562 eMail: oshel@terracom.net

How to Obtain Wrinkle-Free Semi-thin Sections From Plastic Embedded Samples

Thick sections become wrinkled when water is trapped beneath them as they dry on the hot plate. This technique is very effective for ridding sections of unsightly wrinkles:

- 1) Transfer sections from boat to water droplet on glass slide.
- 2) Place slide on hot plate set on warm heat.
- 3) As the sections expand, touch the edge of the water droplet with a wire loop or any other metal prod and "pull" the water droplet from beneath the floating sections. The water is attracted to the metal, so that as the water trails the metal, the sections are left behind. The sections are flattened

against the slide, with no water trapped beneath them. After sufficient drying, the sections may be stained as usual.

Deniefeld W. Player, University of Florida
 dplayer@ufl.edu

A Tip on Solving BEEM Capsule Embedding Problems

BEEM capsules often do not allow for complete fluid exchange at their tips, especially the "conical tip" style capsules. This traps water or ethanol in the samples, which results in poor infiltration and soft blocks.

Increasing your infiltration time may give better results, although given the size of the area over which the exchange has to occur, the infiltration times have to be significantly increased, and the capsules rotated as well. One of the things that I do is to reduce the depth of the cylindrical section by filling it with 100% resin and polymerizing it before I place the sample in the tip. The depth of the cylinder can be tailored by the amount of resin used to fill the tip. When the specimens are ready to section, just cut the blank resin off the end of the block.

One of the side effects of doing this is to reduce the chatter that results from sectioning a long unsupported block tip. I use these style capsules in this manner when I have small amounts of sample that I cannot afford to loose. The method allows me to make a small well to catch the sample, but not have it out on the end of a long cylinder when I go to cut it.

◆ Polaroid

Fresh Polaroid Film. In Stock. Everyday.



- Quality Products
- Knowledgeable Sales Staff
- Competitive Prices
- Same Day Shipments

Call 800.223.7130
 Ext. 3109

Authorized Polaroid
 USA Dealer



226 North Allen Street, Albany, NY 12206
 800.223.7130 x. 3109 fax: 800.832.2205
 www.ngscorp.com e-mail: scisales@ngscorp.com

Modern Coating Solutions for Today's EM Sample Prep Needs



Compact modern desktop systems with fast cycle times. Carbon and sputtering systems for all SEM, FE-SEM and TEM applications.



Cressington Scientific Instruments, Inc.
 508 Thomson Park Drive, Cranberry Twp., PA 16066
 TEL 800-755-1781 / 724-772-0220 FAX 724-772-0219
 Website: www.cressington.com