



MICROSCOPY 101

With this issue, we start a new feature in this publication: a summary of (hopefully) practical and useful hints related to microscopy. Contributions from our readers will be greatly appreciated!

Hanging Drop Slides

To make a hanging drop slide you will need a depression slide, a square coverslip, some petrolatum, and the liquid suspension of what you wish to view.

Place a small spot of petrolatum on each of the 4 corners of the coverslip. Place a drop of your suspension in the center of the coverslip. Invert a depression slide over the drop, allowing the petrolatum to attach the coverslip to the depression slide. Quickly (but carefully) invert the slide so that the coverslip is oriented "up", and the drop is hanging into the slide depression.

W.L. Steffens, University of Georgia, College of Veterinary Medicine.

Clearing Polaroid Negs

For several years now three SEM labs here at the University of Michigan have not been using sulfite baths for treating Polaroid P/N negatives. Instead, they merely

rinse them for an hour or so in warm running water (only slow flow is needed - just enough to keep the water lukish) and then hang them up by the corner to drain and dry on spring clip type clothespins that are strung on a piece of rope or wire. This eliminates the cost of the sulfite bath, the problems of disposing of the spent bath liquor, and the ungodly mess that students always produce by splashing the sulfite solution all over the lab. Try it, you might find it satisfactory for your purposes.

Wil Bigelow, University of Michigan

Rapid Processing of Tissue Samples for TEM

For years I have been using a protocol that allows me to section materials the next day. It is modified from a booklet by Millonig.

Fix in buffered GA (3-4 hr.), rinse (45 min.), osmicate (1 hr.), rinse and dehydrate in acetone (3 hr.), infiltrate and embed in Spurr's (about 1 hr.). Instead of agitating each solution for several hours on a rotator to infiltrate, Millonig recommends using a clinical centrifuge at 2,500 rpm for 10-15 min. for each solution. Polymerize overnight at 70°C. You can section the next morning (though I prefer curing for an additional week).

This technique also eliminates the need to make multiple batches of resin or to freeze the unused resin overnight.

Donald L. Lovett, Trenton State College, Dept. of Biology

De-waxing and Epoxy Embedding

We routinely dewax thick paraffin sections on microscope slides, and then run them up in resin for TEM, with H & E preps of human biopsies. First, we soak off the coverslip with

JEOL 8600 AND 733 ELECTRON PROBE USERS

Bring your probe into the WINDOWS world,
upgrade NOW!

XMAS, a WDS program will provide user friendly,
efficient and **expandable** system for automation and
data reduction.

Many **application specific programs** are available with
XMAS for special applications: i.e., Thin Film
Characterization, Geologic Database with Binary &
Ternary Diagramming and Quantitative Analysis of Low
Concentration Elements.

Don't put the future of your lab in jeopardy!

For more information, contact:

Hessler Technical Serices

PHONE/FAX: (203)358-0266

hestec@ix.netcom.com

AMT introduces...

Charles Bradley

Dr. Bradley has "hands on" experience in AEM,
instrument design and programming. At **AMT**
he is working on applications development,
product design and customer support.



Call **AMT** for:
CCD digital imaging systems
Automated **stage control** systems
Digital imaging **workshop/course info**

Advanced Microscopy Techniques Corp.

3 Electronics Avenue, Danvers, MA 01923
Phone (508)774-5550 Fax (508)739-4313

https://doi.org/10.1017/S155192950005354 Published online by Cambridge University Press